

Silent Gliss® 2020/2120 Systems


Fitting Instructions

WARNING

Parents should realise that children could accidentally strangle in window blind cords. Keep the cords out of the reach of children using one of these devices.



1. Clothes peg or bulldog clip








2. Cleat



3. Tie cord to itself



4. Cord tidy (Silent Gliss part No. 3799)




Silent Gliss® 2020/2120 Systems

Fitting Instructions


1 Top Fixing




2



3



4



0403